



**Captain B Parts List & Schematic Diagram**

PART NO.	DESCRIPTION
1	Pick-Off Points
4	Metal Coupling (7/16" bore for glue roller)
5	Rubber Coupling
6	Allen Screw
7	Metal Coupling (1/2" bore for motor shaft)
8	Black Bodine Fractional Gear Motor
9	Bolt for Motor Plate
10	Brush Cap for <u>Older</u> Black "Bodine" Motor
10BB	Brush Cap for <u>Green</u> "Boehm" Motor
10BR	Brush Cap for <u>Newer</u> Black "Bodine" Motor
10CW	Brush Cap for <u>Black</u> Carter Motor
11 & 12	Carbon Brush for <u>Older</u> Black "Bodine" Motor
11 & 12BB	Carbon Brush for <u>Green</u> "Boehm" Motor
11 & 12BR	Carbon Brush for <u>Newer</u> Black Bodine Motor
11&12C	Carbon Brush for <u>Carter</u> Motor
15	Power Cord
16-8	Glue Tray - 8"
16-10	Glue Tray - 10"
16-14	Glue Tray - 14"
17-8	Cover (only) - 8"
17-10	Cover (only) - 10"
17-14	Cover (only) - 14"
18	Glue Control Washer
19	Glue Control Knob

**For Correct Gluer Size, Measure Glue Roller (Part 23)**

PART NO.	DESCRIPTION
20	Glue Control Spring
21-8	Doctor Blade - 8"
21-10	Doctor Blade - 10"
21-14	Doctor Blade - 14"
22-8	Brass Rod - 8"
22-10	Brass Rod - 10"
22-14	Brass Rod - 14"
23-8	Glue Roller - 8"
23-10	Glue Roller - 10"
23-14	Glue Roller - 14"
24	Screw for Spring Clip
25	Washer for Spring Clip
26	Spring Clip
33	Doctor Blade Screw
34-8/10	Doctor Blade Guide for 8" or 10" Gluer
34-14	Doctor Blade Guide for 14" Gluer (left or right)
36	Finger
37	Screw for Finger
38	Motor Plate with Bolts
39	Motor plate Screw
41	Green Nut
51	Speed Control Dial
52	Built-in Motor Speed Control